

Here are the specs. for the changes on the SmartWi Client.

1. Replace C11 (old value 33pF) with 10nF (SMD0603/50V/X7R)
2. Remove C13
3. Replace R2 with 270R (SMD0603/270R/1%)
4. Place (manual rework) 100nF on top of R2
(Here you can use the 100nF removed at C13, no need to purchase new component)

PS. You can see drawing below...

